



A **KOHLER** COMPANY

CURTIS

Manual

Model 3150R

Digital Instrumentation

» Software Device Profile: 2.0.0.0 «



Curtis Instruments, Inc.

200 Kisco Avenue
Mt. Kisco, NY 10549
www.curtisinstruments.com



Read Instructions Carefully!

Specifications are subject to change without notice. © 2022 Curtis Instruments, Inc.

® Curtis is a registered trademark of Curtis Instruments, Inc. ® Kohler is a registered trademark of Kohler Co.

© The design and appearance of the products depicted herein are the copyright of Curtis Instruments, Inc.

53251 Rev A Oct. 2022

TABLE OF CONTENTS

CHAPTERS

1: OVERVIEW	1
USING THIS MANUAL	1
FEATURES	2
DISPLAY ELEMENTS	2
FAULT CODES	2
LCD HEATER	2
TECHNICAL SUPPORT	2
CONVENTIONS	3
NUMERAL SYSTEM NOTATION	3
MISCELLANEOUS CONVENTIONS	3
2: USING THE 3150R	4
SPEED MODE ICONS	5
TRANSMISSION STATE ICONS	5
SIGNAL ICONS	6
BDI ICON	7
LITHIUM BATTERY VOLTAGE	8
SPEEDOMETER	8
FAULT CODES	9
HOUR METER	11
CHARGING ICON	11
MESSAGE CENTER	12
GUI 3	12
3: INSTALLATION, WIRING AND CONFIGURATION	14
INSTALLATION	14
I/O CONNECTOR	15
I/O PINS	15
WIRING DIAGRAM	16
OPERATING VOLTAGE	16
OPERATING CURRENT	17
I/OS	17
BATTERY CONNECTIONS	17
KEYSWITCH INPUT	17

TABLE OF CONTENTS cont'd

SWITCH INPUTS	17
LIFT LOCKOUT OUTPUT	18
SERIAL COMMUNICATION INTERFACE (SCI) PORT.....	18
CAN CONNECTIONS.....	18
4: PROGRAM MENU PARAMETERS	19
SET HOURMETERS MENU	21
CAN MENU	21
RPDO AND TPDO BYTE MAP MENUS.....	22
BDI MENU.....	25
BDI SETUP MENU	26
MISC MENU.....	27
5: MONITOR MENU PARAMETERS	28
HOURMETERS MENU	28
6: INFORMATION MENU PARAMETERS	29
7: CANopen COMMUNICATIONS	30
BYTE AND BIT SEQUENCE ORDER.....	30
NODE IDs.....	30
BAUD RATE.....	30
MESSAGE CAN-IDs	31
EXPEDITED SDOs.....	31
PDOs.....	32
PDO COB-IDs	32
PDO TIMING	32
PRECONFIGURED PDOs	32
MESSAGE CENTER.....	36
ENABLE AND DISABLE THE MESSAGE CENTER	36
FORMAT MESSAGES.....	37
TRANSMIT MESSAGES	39
CLEAR MESSAGES	39
STANDARD CANopen OBJECTS.....	40
APPENDIX A: CURTIS PROGRAMMING DEVICES	41
APPENDIX B: SPECIFICATIONS	43

TABLE OF CONTENTS cont'd

FIGURES

FIGURE 1-1 CURTIS MODEL 3150R.....	1
FIGURE 3-1 MOUNTING DIMENSIONS	14
FIGURE 3-2 WIRING DIAGRAM.....	16

TABLES

TABLE 2-1 USER INTERFACES.....	4
TABLE 2-2 FAULT SOURCE INDICATORS	9
TABLE 3-1 MATING CONNECTOR PARTS—IP40 PROTECTION	15
TABLE 3-2 MATING CONNECTOR PARTS—IP54 PROTECTION	15
TABLE 4-1 PDO BYTE MAP MENUS — CAN INDEXES AND DEFAULT VALUES	23
TABLE 7-1 GAUGE CONFIGURATION (RPD01, BYTES 6–7)	34



1 – OVERVIEW

The Curtis Model 3150R gauge provides a 1.54 inch (39.1 mm), 240 × 240 pixel LCD that enables visualization of critical information and a unique brand identity through a fully customizable user interface. The device provides five preset user interfaces that can be used as out-of-the-box applications. Curtis engineers can customize the 3150R to meet OEM or market requirements.

Figure 1-1

*Curtis Model
3150R*



All models provide inputs for CAN and a pin that can be configured as either a switch input or a lift lockout driver. Some models include two switch inputs; other models provide two serial communication interface (SCI) inputs for Curtis controllers that support the SCI.

The 3150R complies with relevant US and international regulations. For details on regulatory compliance, see the [Specifications](#) appendix.

USING THIS MANUAL

The next section describes the 3150R's features. The following list describes the chapters that apply to various types of tasks:

- Vehicle operators should read the [Using the 3150R](#) chapter.
- Technicians who work on installation and wiring, or who need information on specifications, should read the [Installation, Wiring and Configuration](#) chapter and the [Specifications](#) appendix.
- Application developers should be familiar with the following chapters:
 - [Program Menu Parameters](#)
 - [Monitor Menu Parameters](#)
 - [CANopen Communications](#)

FEATURES

The following sections describe the 3150R's major features.

Display Elements

The 3150R's display elements include the following:

- Icons that indicate states such as on/off. For example, icons indicate whether the seat belt is on or lift lockout is active.
- Indicators for the active speed mode and transmission state.
- Speedometer.
- Hour meter that indicates the running time of the 3150R, devices on the CANbus, or Curtis controllers that support the SCI.
- Message center that broadcasts custom information.
- Battery discharge indicator (BDI) that shows the battery's state-of-charge.

Fault Codes

The 3150R displays fault codes. The fault data comes from the CANbus or from the SCI.

LCD Heater

The 3150R includes an LCD heater for cold temperatures. When the LCD heater is enabled, the minimum operating temperature is extended to -40°C .

Note: For more information on the 3150R's features, see the data sheet on the Curtis Instruments CAN & Serial Instrumentation page at <https://www.curtisinstruments.com/products/can-serial-instrumentation-programmable/>.

TECHNICAL SUPPORT

For technical support, contact your Curtis distributor or the Curtis sales-support office in your region.

CONVENTIONS

The following topics describe conventions used in this manual.

Numeral System Notation

The following table describes how this manual denotes decimal, binary, and hexadecimal numbers.

Note: The letter *n* in the format column represents a digit.

Numeral System	Format	Example
Decimal	Either of the following: <ul style="list-style-type: none">• <i>nnn</i>• <i>nnnd</i>	<ul style="list-style-type: none">• 127• 127d
Hexadecimal	Either of the following: <ul style="list-style-type: none">• <i>nnnh</i>• 0x<i>nnnn</i>	<ul style="list-style-type: none">• 62Ah• 0x62A
Binary	<i>nnnb</i>	1011b

In addition, some CANopen examples have hexadecimal values without notation. Those examples are formatted with a monospace font and with the bytes delimited by spaces, as shown in the following example:

```
21 FF 01 11 22 01 00 00
```

Miscellaneous Conventions

- *RO* means read-only.
- *RW* means read-write.
- *N/A* means not applicable.

2 – USING THE 3150R

The 3150R provides five user interfaces. The user interfaces are known as GUI *n*, where *n* is a number. GUIs 1, 2, 4 and 5 are for controllers that support CANopen. GUI 3 is for controllers that support the serial communication interface.

The following table summarizes the user interfaces.

Table 2-1 User Interfaces

User Interface	Example	Description
GUI 1		Displays all 3150R functions other than lithium battery voltage.
GUI 2		Displays all 3150R functions other than lithium battery voltage. Many of GUI 2's icons look differently than those for GUIs 1, 4 and 5.
GUI 3		Displays the following items for Curtis controllers that support the SCI: <ul style="list-style-type: none"> • Speed mode • Parking brake status • BDI status • Fault codes • Hour meter
GUI 4		Designed for applications that display lithium battery voltage. The difference between GUI 4 and GUI 1 is that GUI 4 displays the lithium battery voltage in the area where GUI 1 displays the speed. GUI 4 displays the speed below the battery voltage.
GUI 5		Designed for applications that prominently display the remaining battery charge. GUI 5 does not provide a speedometer and does not support faults for dual traction controllers, hydraulic pumps and steering controllers.

The following topics describe GUIs 1, 2, 4 and 5. GUI 3 has significant differences with the other user interfaces and is [described separately](#).

SPEED MODE ICONS

A controller's speed mode determines the active acceleration and deceleration rates and maximum forward and reverse speeds. The speed modes balance fuel economy and vehicle power.

The speed mode icons indicate the controller's active speed mode. All GUIs other than GUI 3 provide the following icons:

Speed Mode	Description	Icon (GUIs 1, 4 and 5)	Icon (GUI 2)
High mode	The speed mode with the fastest maximum speeds and acceleration/deceleration rates. Note: High mode and power mode have the same characteristics. Some OEMs describe this mode as high mode, others as power mode.		
Economy mode	Maximizes fuel economy by providing lower maximum speeds and acceleration/deceleration rates than high, power and standard modes.		
Turtle mode	The speed mode with the slowest maximum speeds and acceleration/deceleration rates.		
Standard mode	A balance of maximum speeds, acceleration/deceleration rates and fuel efficiency.		
Power mode	Power mode has the same characteristics as high mode.		

TRANSMISSION STATE ICONS

The following table describes icons that indicate the controller's transmission state:

Transmission State	Icon (GUIs 1, 4 and 5)	Icon (GUI 2)
Forward gear		
Reverse gear		
Neutral		

SIGNAL ICONS

The signal icons display on the top of the screen and indicate vehicle actions and states. The following table describes the signal icons and the conditions that cause them to display.

Note: If there are more active icons than can be simultaneously displayed, the device will cycle through the icons.

Function	Display Condition	Icon
Lift lock	Lift lockout is active.	
Guardrail	Reminds the vehicle operator to close the guardrail for safety purposes. The guardrail icon is typically used for order pickers.	
Parking brake	The parking brake is set.	
Safety pedal	The safety pedal is active.	
Seat	The vehicle operator has left the seat.	
Seat belt	The vehicle operator is not wearing the seatbelt.	
Lift	The lift function is active.	
Lower	The lower function is active.	
Fault	The controller is reporting one or more active faults.	
Low BDI alarm	The battery's state of charge is low.	

BDI ICON

The BDI icon uses color to indicate the BDI percentage, which measures the amount of remaining battery charge. The color reflects whether the battery is sufficiently charged, is starting to get low, or is in urgent need of charging. The BDI percentages that define these statuses depend upon how the 3150R is configured.

In all user interfaces other than GUI 2, the icon displays the BDI percentage. GUI 2 uses a battery at the bottom of the icon to indicate the approximate BDI percentage.

The following table describes the BDI icon.

Note: The examples below are for a configuration where the BDI status is Warning when the BDI percentage is between 10–19% and Low when the BDI percentage is between 0–9%.

BDI Status	GUIs 1, 3, 4 and 5	GUI 2	Comments
Okay			
Warning			When the BDI status is Warning, the low BDI alarm icon, , flashes.
Low			When the BDI status is Low, the low BDI alarm icon flashes, the lift is locked and the lift lock icon, , flashes.

LITHIUM BATTERY VOLTAGE

GUI 4 displays the lithium battery voltage. The text “Li” displays under the voltage:




SPEEDOMETER

GUIs 1, 2 and 4 display a speedometer. The speed is displayed in km/h or mph, depending upon how the device is configured.

In GUIs 1 and 2, the speedometer is prominently displayed and looks as follows:



In GUI 1, if a fault is active and the transmission state is not neutral, the fault codes display in the speedometer area and the speed is displayed below the fault codes:



In GUI 2, if a fault is active the speedometer is hidden for five seconds. After five seconds the speedometer is restored and the fault code displays above it:




In GUI 4, the speedometer is displayed under the lithium battery voltage:



FAULT CODES

The user interfaces have different ways of displaying fault codes, as described in the following table.

Note: If there are more faults than the active user interface can display simultaneously, the 3150R periodically cycles through the fault codes.

GUI(s)	Example	Comments
GUIs 1 and 4		<p>The screen displays up to three fault codes simultaneously. The details depend upon the GUI:</p> <ul style="list-style-type: none"> • GUI 1: Fault codes display in the speedometer area. If the transmission state is not neutral, the speedometer displays below the fault codes. • GUI 4: Fault codes display in the lithium battery voltage area. The voltage is hidden. If the transmission state is not neutral, the speedometer displays below the fault codes.
GUI 2		<p>The screen displays one fault code at a time. A warning symbol displays above the fault code. When a fault is active, the speedometer is hidden for five seconds. After five seconds the speedometer is restored and the fault code displays above it.</p>
GUI 5		<p>The screen displays one fault code at a time. GUI 5 is not designed to display faults for the following controllers:</p> <ul style="list-style-type: none"> • Dual traction (left and right controllers) • Pump • Steering

Fault codes are preceded by *fault source indicators* that identify the components with active faults. The fault source indicators depend upon the user interface:

Table 2-2 Fault Source Indicators

Fault Source	GUIs 1 and 4	GUI 2	GUI 5
Traction controller	T	TRA	TRA
Right traction controller	TR	TRA_R	N/A
Left traction controller	TL	TRA_L	N/A
Pump controller	P	HYD	N/A
Steering controller	S	STR	N/A
BMS (Battery Management System)	B	BAT	BAT
Lift lock driver (Overcurrent) Note: This fault does not have a fault code.	OC	OverCurrent	OC

The fault code format depends upon the active user interface. The following table describes how the user interfaces display two-character fault codes for traction, pump and steering controller faults. The fault code characters range from 0–9 and A–F:

GUI(s)	Description
GUIs 1 and 4	<p>Faults are displayed in the following format:</p> <ul style="list-style-type: none"> • Fault source indicator • The fault code, which consists of a character, a comma, and another character. • If the fault has a fault type, the fault type is displayed within brackets. <p>In the following example, the traction and pump faults have fault types and the BMS fault does not:</p> <div style="background-color: black; color: yellow; padding: 5px; display: inline-block;"> T B, 1 [1] P 8, 5 [2] B 023 </div>
GUI 2	<p>Faults are displayed in the following format:</p> <ul style="list-style-type: none"> • Fault source indicator • A colon • The fault code, which consists of a character, a period, and another character. <div style="background-color: black; color: yellow; padding: 5px; display: inline-block;"> TRA: 1.2 </div> <p>Note: GUI 2 does not display fault types.</p>
GUI 5	<p>Faults are displayed in the following format:</p> <ul style="list-style-type: none"> • Fault source indicator • A colon • The fault code, which consists of a character, a comma, and another character. • If the fault has a fault type, the fault type is displayed within brackets. <div style="background-color: black; color: yellow; padding: 5px; display: inline-block;"> TRA: 1,2 [2] </div>

BMS and lift lock driver overcurrent faults have different formats:

- BMS fault codes consist of three characters:

BAT:013

- Lift lock driver Overcurrent faults do not have fault codes. Instead, the screen displays only the fault source indicator (OC or OverCurrent) described in Table 2-2. The following example is from GUI 2:



HOUR METER

The hour meter indicates the running time of the 3150R, devices on the CANbus, or Curtis controllers connected to the SCI ports. The first example below is for GUIs 1, 4 and 5, and the second is for GUI 2:



The hour meter measures time in 0.1 hour units. The maximum value is 99,999.9 hours. After the hour meter reaches its maximum value, the hour meter resets to 0.0 hours.


CHARGING ICON

To indicate that the battery is charging, a charging icon replaces the [BDI icon](#). GUI 2 has a different icon than GUIs 1, 4 and 5:

User Interface(s)	Example
GUIs 1, 4 and 5	A circular display showing a battery icon with a lightning bolt, the number "58%", and the letters "N" and "S". Below the display is the word "CURTIS".
GUI 2	A circular display showing a battery icon with a lightning bolt, the number "34%", and the letters "S" and "N". Below the display is the word "CURTIS".

MESSAGE CENTER

The device provides a message center. The messages that are broadcast depend upon how the device is configured. Messages are displayed within a rectangular area and can be formatted with different font sizes and colors. In the following example, the message consists of three lines that begin with “Information”, “Speed”, and “Fault”:



GUI 3

GUI 3 is designed for Curtis controllers that support the serial communication interface. GUI 3 displays the following screen while the 3150R waits for the controller to connect:



When the controller connects with the 3150R, the main GUI 3 screen is displayed:



The following table describes the items contained by GUI 3:

Item	Description
	The controller's active speed mode: M1 = Speed mode 1 M2 = Speed mode 2
	Displays when the parking brake is active.
	The BDI icon. For information on the colors that indicate the BDI status, see BDI Icon .
	Displays a fault code when the controller has an active fault.
	The hour meter, which indicates the running time of the 3150R or the controller, depending upon how the device is configured. The hour meter measures time in 0.1 hour units. The maximum value is 99,999.9 hours. After the hour meter reaches its maximum value, the hour meter resets to 0.0 hours.

3 – INSTALLATION, WIRING AND CONFIGURATION

This chapter explains how to install and wire Model 3150R.

INSTALLATION

Fix the 3150R by using the provided mounting bracket. The recommended panel cutout is $\varnothing 52.0 \pm 0.4$ mm, with a panel thickness between 0.8–6.4 mm.




Figure 3-1
Mounting Dimensions

I/O CONNECTOR

The mating connector is an 8-pin Mini-Universal MATE-N-LOK housing from TE Connectivity. The front is sealed to IP67. The rear is sealed to IP65 for electronic components and IP40 for the connector. You can increase the connector's protection to IP54 by using the parts listed in Table 3-2.

The following tables list the TE Connectivity parts for IP40 and IP54 protection.

Table 3-1 Mating Connector Parts—IP40 Protection

Part	TE Connectivity Part Number
Connector Housing	770579-1
Terminal (18–22 AWG)	770904-X

Table 3-2 Mating Connector Parts—IP54 Protection

Part	TE Connectivity Part Number
Connector Housing	794821-1
Terminal (18–22 AWG)	770904-X
Interface Seal	794772-8
Single Wire Seal or Gang Seal	794758-1 or 1586359-8
Cavity Plug Seal (for unused terminal positions)	794995-1

I/O PINS

The following table describes the I/O pins.


Pin	Signal Name	Description
1	CAN Low	CANbus low signal
2	CAN High	CANbus high signal
3	B-	Battery negative
4	B+	Battery positive
5	SCI Tx / SW1	Serial communication interface Tx or Switch 1 Note: Some models use pins 5–6 for a serial port, other models use these pins for Switch 1 and Switch 2.
6	SCI Rx / SW2	Serial communication interface Rx or Switch 2
7	KSI	Keystswitch
8	Lift Lockout Output / SW3	Lift lockout output or Switch 3

WIRING DIAGRAM

Figure 3-2 is a typical wiring diagram for a model with a serial port and with pin 8 configured as a lift lockout output.

Note: The diagram may differ from your application's requirements. However, Model 3150R provides the I/Os and programmable parameters needed to meet almost all requirements. To discuss how to implement your application, contact your Curtis distributor or the Curtis sales and support office in your region.

Figure 3-2
Wiring Diagram



OPERATING VOLTAGE

The following table describes the operating voltages:

Minimum Voltage	Nominal Voltage	Maximum Voltage
9V	12-48V	60V

The 3150R withstands reverse polarity connections continuously.

Note: All voltages listed in this manual are DC voltages. Use the [Nominal Voltage](#) parameter to specify the voltage for your application.

OPERATING CURRENT

The operating current depends upon the B+ voltage and whether the LCD heater is enabled:

B+ Voltage	LCD Heater Disabled	LCD Heater Enabled
9V	100mA	350mA
12V	72mA	390mA
24V	36mA	200mA
36V	25mA	140mA
48V	20mA	100mA
60V	16mA	80mA

Note: The [LCD Heater Enable](#) parameter enables the heater.

I/Os

The following topics describe how to connect and configure the I/Os.

Battery Connections

Connect the battery to the B– and B+ inputs (pins 3 and 4). Curtis recommends that you include a fuse in the circuit that connects the battery to the B+ input, as shown in [Figure 3-2](#). The fuse protects the power system from external shorts. Size the fuse according to the application's requirements.

Keyswitch Input

Connect a keyswitch to the keyswitch (pin 7) and B+ inputs. The operating voltage is the same as the device's [operating voltage](#). The input is active high when switched to B+.

Switch Inputs

Model 3150R provides up to three switch inputs. Some models use pins 5–6 as the Switch 1 and Switch 2 inputs, while other models use pins 5–6 as a serial port.

All models include the Switch 3 input (pin 8). Pin 8 can also be used as a lift lockout output. To configure pin 8 as the Switch 3 input, set the 32 bit CAN object 0x6709 : 05 to 1.

The switch inputs are active high when switched to B+. The inputs' operating voltages are the same as the device's operating voltage. The following table describes the switch input specifications:

Specification	Minimum	Maximum
Input Active High Threshold Voltage	6.0V	The maximum B+ voltage
Input Impedance	148kΩ	152kΩ

Lift Lockout Output

Pin 8 can be configured as a lift lockout output. The output is active when the BDI percentage is less than the percentage specified by the [Lift Lockout](#) parameter. The output withstands voltage turn-off spikes that are typical of inductive loads.

To configure pin 8 as a lift lockout output, set the 32-bit CAN object 0x6709 : 05 to 0.

The following table describes the lift lockout driver specifications:

Specification	Minimum	Maximum	Condition
Continuous Current	0A	0.5A	N/A
Off Voltage	N/A	75V	N/A
On Voltage	0V	1V	I = 1A DC

Serial Communication Interface (SCI) Port

Some models use pins 5-6 as an SCI port. The port is used to read the following data from Curtis controllers that support the SCI:

- BDI percentage
- Hour meter
- Speed mode
- Parking brake status
- Fault codes

When a controller is connected to the serial port, the 3150R automatically gets speed mode, parking brake status and fault code data from the controller. The gauge also gets the BDI percentage and hour meter data from the controller if the following parameters specify SCI:

- [BDI Source](#)
- [Hourmeter Source](#)

Note: GUI 3 displays data for the controller connected to the serial port.

CAN Connections

To connect the gauge to the CANbus, connect CAN Low and CAN High to pins 1 and 2. Use twisted-pair wiring to minimize the likelihood of picking up a voltage bias on only one signal.

Some models include a 120Ω terminating resistor.

Note: For information on Model 3150R's CAN parameters and features, see [CAN Menu](#) and [CANopen Communications](#).

4 – PROGRAM MENU PARAMETERS

SET HOURMETERS MENU..... p. 21	BDI MENU..... p. 25	MISC MENU..... p. 27
— Hourmeter Source	— Nominal Voltage	— HYD Controller Enable
— Reset KSI Hourmeter	— BDI Source	— Speed Unit
— Set KSI Hourmeter	— Lift Lockout	— GUI Select
CAN MENU..... p. 21	— BDI Low Alarm	— Logo Select
— CAN Node ID	BDI SETUP MENU..... p. 26	— LCD Heater Enable
— CAN Baud Rate	— Charge Full	
— Auto Operation	— Charge Empty	
— Message Center Node ID	— Discharge Full	
RPDO AND TPDO BYTE	— Discharge Empty	
MAP MENUS..... p. 22	— OCR Reset	
— Length	— Integration Rate	
— Map 1		
— Map 2		
— Map 3		
— Map 4		
— Map 5		
— Map 6		
— Map 7		
— Map 8		

The programmable parameters allow you to configure the gauge so that it meets your application's requirements. [Curtis programming devices](#) provide a user-friendly way to read and write to the parameters.

Restart the device after you change a parameter marked as [PCF]. If the device is not restarted, a Parameter Change fault will occur.

The parameters are grouped into menus. This chapter describes the main menu and the menus contained by the Program menu. The gauge also provides read-only parameters on the [Monitor menu](#) and [Information menu](#).

The following columns in the parameter description tables contain multiple types of information:

- **Parameter and CAN Index:** The parameter name, followed by the CAN index and sub-index. This column also identifies parameters marked as [PCF].
Note: CAN indexes and sub-indexes are delimited by colons. For example, a parameter with an index of 0x640F and a sub-index of 0x00 would be represented as 0x640F:00.
- **Values and Raw Values:** The allowed values as displayed in Curtis programming devices, followed by allowed values in raw units suitable for CAN messages.
- **Access Level and Default Value.** The parameter's access level for Curtis programming devices, followed by the default value.

Note: Writes to parameters are automatically saved to the 3150R's EEPROM. A “save” command using the CANopen Store Parameters object (0x1010:01) is not required.

SET HOURMETERS MENU

The following table describes the parameters for configuring the hour meter.

SET HOURMETERS MENU

PARAMETER CAN INDEX	VALUES RAW VALUES	DATA SIZE	ACCESS LEVEL DEFAULT VALUE	DESCRIPTION
Hourmeter Source 0x6709:00	Enumerated 0–2	32-bit	OEM Dealer 3150	Specifies the data source for the hour meter: 0 = 3150 1 = CAN 2 = SCI
Reset KSI Hourmeter 0x6451:00	Off/On 0–1	32-bit	OEM Dealer Off	Resets the 3150R's keyswitch hour meter.
Set KSI Hourmeter 0x6414:00	0–99999.9 hours 0–99999	32-bit	OEM Dealer 0.0 hr	Specifies the time indicated by the 3150R's keyswitch hour meter.

CAN MENU

The following table describes the parameters on the CAN menu.

Note: The CAN menu also contains the RPDO 1–4 Byte Map and TPDO 1–4 Byte Map menus, which specify the objects for which the PDOs transmit and receive data.

CAN MENU

PARAMETER CAN INDEX	VALUES RAW VALUES	DATA SIZE	ACCESS LEVEL DEFAULT VALUE	DESCRIPTION
CAN Node ID 0x2000:01	1–127 1–127	32-bit	OEM Dealer 46	Specifies the device's node ID.
CAN Baud Rate 0x2001:01	-1 to 4 -1 to 4	32-bit	OEM Dealer 0	Specifies the baud rate: -1 = 100 Kbps 0 = 125 Kbps 1 = 250 Kbps 2 = 500 Kbps 3 = 800 Kbps 4 = 1 Mbps
Auto Operation 0x6557:00	0–1 0–1	32-bit	OEM Dealer 1	Specifies the NMT state when the device powers up: 0 = Pre-operational 1 = Operational
Message Center Node ID 0x7022:00	1–127 1–127	32-bit	OEM Dealer 80	Specifies the node ID for the message center.

RPDO and TPDO Byte Map Menus

The parameters on the RPDO 1–4 Byte Map and TPDO 1–4 Byte Map menus are used to configure PDOs. RPDOs 1–3 and TPDO1 are [preconfigured](#). Modify a preconfigured PDO only if the application does not require the PDO's preconfigured functions.

The menus contain parameters with the same names, allowed values, and data sizes. The only differences between parameters of the same name are their CAN indexes and default values. The following table describes the PDO Byte Map menus' parameters and [Table 4-1](#) lists the parameters' CAN indexes and default values.

CAN MENU — RPDO AND TPDO BYTE MAP MENU

PARAMETER	VALUES RAW VALUES	DATA SIZE	ACCESS LEVEL	DESCRIPTION
Length	0–8 0–8	8-bit	OEM Dealer	Specifies the number of objects mapped to the PDO.
Map 1	0–FFFFFFFh 0–FFFFFFFh	32-bit	OEM Dealer	Specifies the PDO's first mapped object.
Map 2	0–FFFFFFFh 0–FFFFFFFh	32-bit	OEM Dealer	Specifies the PDO's second mapped object.
Map 3	0–FFFFFFFh 0–FFFFFFFh	32-bit	OEM Dealer	Specifies the PDO's third mapped object.
Map 4	0–FFFFFFFh 0–FFFFFFFh	32-bit	OEM Dealer	Specifies the PDO's fourth mapped object.
Map 5	0–FFFFFFFh 0–FFFFFFFh	32-bit	OEM Dealer	Specifies the PDO's fifth mapped object.
Map 6	0–FFFFFFFh 0–FFFFFFFh	32-bit	OEM Dealer	Specifies the PDO's sixth mapped object.
Map 7	0–FFFFFFFh 0–FFFFFFFh	32-bit	OEM Dealer	Specifies the PDO's seventh mapped object.
Map 8	0–FFFFFFFh 0–FFFFFFFh	32-bit	OEM Dealer	Specifies the PDO's eighth mapped object.

Table 4-1 PDO Byte Map Menus – CAN Indexes and Default Values

PARAMETER	PDO	CAN INDEX	DEFAULT VALUE
Length	RPD01	0x1600:00	7
Map 1	RPD01	0x1600:01	0x66020008
Map 2	RPD01	0x1600:02	0x6B000008
Map 3	RPD01	0x1600:03	0x6A010008
Map 4	RPD01	0x1600:04	0x66070008
Map 5	RPD01	0x1600:05	0x66080010
Map 6	RPD01	0x1600:06	0x66000008
Map 7	RPD01	0x1600:07	0x66010008
Map 8	RPD01	0x1600:08	0
Length	TPD01	0x1A00:00	5
Map 1	TPD01	0x1A00:01	0x66090008
Map 2	TPD01	0x1A00:02	0x660A0008
Map 3	TPD01	0x1A00:03	0x660B0008
Map 4	TPD01	0x1A00:04	0x660C0008
Map 5	TPD01	0x1A00:05	0x64140020
Map 6	TPD01	0x1A00:06	0
Map 7	TPD01	0x1A00:07	0
Map 8	TPD01	0x1A00:08	0
Length	RPD02	0x1601:00	6
Map 1	RPD02	0x1601:01	0x65100010
Map 2	RPD02	0x1601:02	0x65120010
Map 3	RPD02	0x1601:03	0x66040008
Map 4	RPD02	0x1601:04	0x6B020008
Map 5	RPD02	0x1601:05	0x66050008
Map 6	RPD02	0x1601:06	0x6A020008
Map 7	RPD02	0x1601:07	0
Map 8	RPD02	0x1601:08	0
Length	TPD02	0x1A01:00	0
Map 1	TPD02	0x1A01:01	0
Map 2	TPD02	0x1A01:02	0
Map 3	TPD02	0x1A01:03	0
Map 4	TPD02	0x1A01:04	0
Map 5	TPD02	0x1A01:05	0
Map 6	TPD02	0x1A01:06	0
Map 7	TPD02	0x1A01:07	0
Map 8	TPD02	0x1A01:08	0
Length	RPD03	0x1602:00	4
Map 1	RPD03	0x1602:01	0x66030008
Map 2	RPD03	0x1602:02	0x6B010008
Map 3	RPD03	0x1602:03	0x6A000008
Map 4	RPD03	0x1602:04	0x6B030008
Map 5	RPD03	0x1602:05	0
Map 6	RPD03	0x1602:06	0
Map 7	RPD03	0x1602:07	0
Map 8	RPD03	0x1602:08	0

Table 4-1 PDO Byte Map Menus — CAN Indexes and Default Values, cont'd

PARAMETER	PDO	CAN INDEX	DEFAULT VALUE
Length	TPD03	0x1A02:00	0
Map 1	TPD03	0x1A02:01	0
Map 2	TPD03	0x1A02:02	0
Map 3	TPD03	0x1A02:03	0
Map 4	TPD03	0x1A02:04	0
Map 5	TPD03	0x1A02:05	0
Map 6	TPD03	0x1A02:06	0
Map 7	TPD03	0x1A02:07	0
Map 8	TPD03	0x1A02:08	0
Length	RPD04	0x1603:00	0
Map 1	RPD04	0x1603:01	0
Map 2	RPD04	0x1603:02	0
Map 3	RPD04	0x1603:03	0
Map 4	RPD04	0x1603:04	0
Map 5	RPD04	0x1603:05	0
Map 6	RPD04	0x1603:06	0
Map 7	RPD04	0x1603:07	0
Map 8	RPD04	0x1603:08	0
Length	TPD04	0x1A03:00	0
Map 1	TPD04	0x1A03:01	0
Map 2	TPD04	0x1A03:02	0
Map 3	TPD04	0x1A03:03	0
Map 4	TPD04	0x1A03:04	0
Map 5	TPD04	0x1A03:05	0
Map 6	TPD04	0x1A03:06	0
Map 7	TPD04	0x1A03:07	0
Map 8	TPD04	0x1A03:08	0

BDI MENU

The following table describes the parameters on the BDI menu.

Note: The BDI menu contains the BDI Setup menu.

BDI MENU

PARAMETER CAN INDEX	VALUES RAW VALUES	DATA SIZE	ACCESS LEVEL DEFAULT VALUE	DESCRIPTION
Nominal Voltage 0x6555:00	Enumerated 0–3	32-bit	OEM Dealer 24V	Specifies the battery's nominal voltage: 0 = 12V 1 = 24V 2 = 36V 3 = 48V
BDI Source 0x6709:01	Enumerated 0–2	32-bit	OEM Dealer 3150	Specifies the data source for the BDI data: 0 = 3150 1 = CAN 2 = SCI (serial)
Lift Lockout 0x6408:00	0.0–20.0% 0–200	32-bit	OEM Dealer 10.0%	Specifies the BDI percentage below which lift lockout and the low BDI alarm are activated and the BDI icon is red.
BDI Low Alarm 0x640A:00	0–50.0% 0–500	32-bit	OEM Dealer 20.0%	Specifies the BDI percentage below which the low BDI alarm is activated. When the BDI percentage is below BDI Low Alarm and greater than or equal to Lift Lockout, the BDI icon is yellow.

BDI Setup Menu

The BDI Setup menu is displayed when the 3150R is the data source for BDI data. The parameters configure how the gauge calculates the BDI percentage.

BDI MENU — BDI SETUP MENU

PARAMETER CAN INDEX	VALUES RAW VALUES	DATA SIZE	ACCESS LEVEL DEFAULT VALUE	DESCRIPTION
Charge Full 0x6404 : 00	1.500–2.500V 1500–2500	32-bit	OEM Dealer 2.350V	Specifies the battery cell voltage above which the battery is considered charged. Charge Full must be at least 0.200V above Charge Empty.
Charge Empty 0x6405 : 00	1.500–2.500V 1500–2500	32-bit	OEM Dealer 2.100V	Specifies the battery cell voltage above which the battery is considered as starting to charge. Charge Empty must be at least 0.200V below Charge Full and at least 0.010V above Discharge Full.
Discharge Full 0x6402 : 00	1.500–2.500V 1500–2500	32-bit	OEM Dealer 2.040V	Specifies the battery cell voltage at which the state of charge is considered 100%. Discharge Full must be at least 0.120V more than Discharge Empty and must be between the following values: <ul style="list-style-type: none">• Charge Empty: 0.010V• OCR Reset: 0.030V
Discharge Empty 0x6403 : 00	1.500–2.500V 1500–2500	32-bit	OEM Dealer 1.730V	Specifies the battery cell voltage at which the state of charge is considered 0%. Discharge Empty must be at least 0.120V below Discharge Full.
OCR Reset 0x6406 : 00	1.500–2.500V 1500–2500	32-bit	OEM Dealer 2.090V	Specifies the battery cell voltage above which the BDI percentage is reset to 100%. OCR Reset is checked only once; the check occurs when the gauge is powered up. OCR Reset must be at least 0.030V above Discharge Full and at least 0.010V less than Charge Empty.
Integration Rate 0x6407 : 00	2–600 minutes 2–600	32-bit	OEM Dealer 30 minutes	Specifies the minimum time for the BDI algorithm to decrease the BDI percentage from 100% to 0% or increase the percentage from 0% to 100%.

MISC MENU

The following table describes the parameters on the Misc menu.

MISC MENU

PARAMETER CAN INDEX	VALUES RAW VALUES	DATA SIZE	ACCESS LEVEL DEFAULT VALUE	DESCRIPTION
HYD Controller Enable 0x6556:00	Off/On 0–1	32-bit	OEM Dealer On	Specifies whether fault codes for the hydraulic controller are displayed.
Speed Unit 0x6021:00	Enumerated 0–1	32-bit	OEM Dealer KPH	Specifies the speedometer's unit of measurement: 0 = KPH 1 = MPH
GUI Select 0x6709:02	Enumerated 0–4	32-bit	OEM Dealer GUI-1	Specifies the user interface: 0 = GUI-1 1 = GUI-2 2 = GUI-3 3 = GUI-4 4 = GUI-5
Logo Select 0x6553:00	0–1 0–1	32-bit	OEM Dealer 0	Indicates whether a logo displays after the device first powers up. 0 = No logo 1 = Curtis logo
LCD Heater Enable 0x6709:03	Off/On 0–1	32-bit	OEM Dealer On	Indicates whether the LCD heater is disabled. Note: If the gauge is powered by the external 12V supply of a Curtis motor controller, disable the LCD heater. This is because of the controllers' external power supply limits.

5 – MONITOR MENU PARAMETERS

The Monitor menu contains the Hourmeters menu.

HOURMETERS MENU.....	p. 28
— KSI Hourmeter	

HOURMETERS MENU

The following table describes the KSI Hourmeter parameter.

HOURMETERS MENU

PARAMETER CAN INDEX	VALUES RAW VALUES	DATA SIZE	ACCESS LEVEL	DESCRIPTION
KSI Hourmeter 0x6700 : 00	0.0–99999.9 hours 0–99999	32-bit	Field Basic	Indicates how many hours are on the keyswitch hour meter.

6 – INFORMATION MENU PARAMETERS

The Information menu contains the following read-only parameters:

INFORMATION MENU

PARAMETER CAN INDEX	VALUES RAW VALUES	DATA SIZE	ACCESS LEVEL	DESCRIPTION
Model Number 0x6505:00	-32768 to 32767 -32768 to 32767	32-bit	Field Basic	Indicates the model number.
Serial Number 0x1018:04	0-999999 0-999999	32-bit	Field Basic	Indicates the serial number.
CDEV 0x6501:00	-2147483648 to 2147483647 -2147483648 to 2147483647	32-bit	Field Basic	Indicates the device profile's version.
OS Version 0x6500:00	-2147483648 to 2147483647 -2147483648 to 2147483647	32-bit	Field Basic	Indicates the operating system's version.

7 – CANopen COMMUNICATIONS

Model 3150R complies with the CAN in Automation (CiA) CANopen 301 specification. This chapter describes the gauge's CANopen features.

Some familiarity with CANopen is a prerequisite. For CANopen information, see the following pages on the CiA web site:

- Overview: <https://www.can-cia.org/canopen/>
- Specifications: <https://www.can-cia.org/groups/specifications/>

BYTE AND BIT SEQUENCE ORDER

CANopen message byte sequences are transmitted with the least significant byte first (little-endian format).

Note: This manual uses the LSB 0 Numbering convention when referring to byte and bit numbers.

For example, the following table shows an SDO that writes the data 04E2h to the object with the index and sub-index 334C-01h:

0	1	2	3	4	5	6	7
Control Byte	Index		Sub-index	Data			
2Bh	4Ch	33h	01h	E2h	04h	00h	00h

Strings are read from left to right. The following example shows how the 3150R transmits an SDO segment for the string "Curtis":

0	1	2	3	4	5	6	7
Control Byte	Data						
00h	43h = "C"	75h = "u"	72h = "r"	74h = "t"	69h = "i"	73h = "s"	

Bit sequences are transmitted from most significant to least significant bit (big-endian format). The following example shows how the gauge transmits the bits for the value 2Bh:

7	6	5	4	3	2	1	0
0	0	1	0	1	0	1	1

NODE IDs

Model 3150R's node ID is specified with the CAN Node ID parameter. The default node ID is 0x2E.

The message center has its own node ID, which is specified with the Message Center Node ID parameter. The message center's default node ID is 0x50.

Note: Both parameters are on the [CAN menu](#).

BAUD RATE

The gauge's baud rate is specified with the CAN Baud Rate parameter on the CAN menu. The default baud rate is 125 Kbps.

MESSAGE CAN-IDs

The 3150R's CAN messages are identified by 11-bit CAN IDs. The device does not support 29-bit CAN IDs.

EXPEDITED SDOs

The least significant byte of an expedited SDO is known as the *control byte*. The following table describes the control byte fields:

7	6	5	4	3	2	1	0
<i>Command Specifier</i>				0b	<i>n</i>	<i>e</i>	<i>s</i>

The following list describes the control byte:

- The *Command Specifier* field indicates the SDO's transfer type. The following table describes the transfer types:

Transfer Type	Value
Write data to a device	001b
Confirm a write	011b
Request data from a device	010b
Device responds with requested data	010b
Abort SDO	100b

- Bit 4 is always 0b.
- The values of bits 0–3 depend upon whether the SDO transfers data. If the SDO does **not** transfer data, these bits are always 0b. If the SDO transfers data, the bit values are as follows:
 - *n* indicates the number of unused data bytes.
 - *e* = 1b, which indicates the message contains data.
 - *s* = 1b, which indicates that the *n* field specifies the number of unused data bytes.

The following table lists the control byte values for the various transfer types:

Transfer Type	Control Byte
Write data to a device	Depends upon the data size: <ul style="list-style-type: none"> • 1 byte = 2Fh • 2 bytes = 2Bh • 3 bytes = 27h • 4 bytes = 23h
Confirm a write	60h
Request data from a device	40h
Device responds with requested data	Depends upon the data size: <ul style="list-style-type: none"> • 1 byte = 4Fh • 2 bytes = 4Bh • 3 bytes = 47h • 4 bytes = 43h
Abort SDO	80h

PDOs

RPDOs 1–3 and TPDO 1 and are preconfigured to transmit and receive data used by Model 3150R's user interfaces. The following topics describe PDO considerations and the preconfigured PDOs.

Note: RPDO4 and TPDOs 2–4 are reserved.

PDO COB-IDs

The following table lists the bits that define a PDO COB-ID:

Bit(s)	Description
31	Indicates whether the PDO is enabled. 0b indicates enabled.
30	<i>Reserved.</i> Always 0.
29	Indicates whether the COB-ID is 11 or 29 bits. The device supports only 11-bit COB-IDs, so the value is always 0.
11–28	Bits that would be set for 29-bit COB-IDs. For the 3150R, these bits = 0.
7–10	The PDO's function code. The function codes are listed below: <ul style="list-style-type: none"> • RPDO1: 0100b • RPDO2: 0110b • RPDO3: 1000b • RPDO4: 1010b • TPDO1: 0011b • TPDO2: 0101b • TPDO3: 0111b • TPDO4: 1001b
0–6	The device's node ID.

For example, if the device's node ID is 2Eh and RPDO1 is enabled, the RPDO1 COB-ID is 22Eh.

PDO Timing

The 3150R's PDOs are asynchronous and are periodically transmitted and received. The device does not support synchronous PDOs. The following list describes the PDOs' event times:

- RPDOs: 60,000ms (1 minute). If the device does not receive data within one minute, it displays *.*.
- TPDOs: 40ms

Preconfigured PDOs

Some RPDO bytes receive fault codes and fault types for traction, pump and steering controllers. The following list describes the data for these bytes:

- Fault codes: The four most significant bits are the fault code's first character and the four least significant bits are the second character. The fault code characters range from 0–9 and A–F. 0h indicates that the component does not have an active fault. For example, if a device's fault code byte specifies B2h, the fault code is B2.
- Fault types: The fault types range from 0–99. The raw data ranges from 0–63h. 0 indicates that the fault does not have a fault type.

The following topics describe the preconfigured PDOs.

RPDO1

Byte(s)	Description
0	The fault code for the traction controller. If RPDO2, byte 6, bit 5 is set to 1, the fault code is for the right traction controller.
1	The fault type for the traction controller. If RPDO2, byte 6, bit 5 is set to 1, the fault type is for the right traction controller.
2	The fault code for the BMS. Fault codes range from 1–255. When a BMS fault is active, the device displays the fault code only if the fault type is less than the value specified by the <code>bat_fault_active_level</code> parameter. The parameter has a CAN index and sub index of <code>0x6558 : 00</code> and a default value of 3.
3–5	The hour meter data: <ul style="list-style-type: none"> Byte 3 indicates the data's last two numbers. The data ranges from 0–63h, which represents 0–9.9. Bytes 4–5 indicate the data's first four numbers. The data ranges from 0–270Fh, which represents 0–9999. For example, if byte 3 specifies 63h and bytes 4–5 specify 270Fh, the hour meter displays 99999.9 hours.
6	Indicates states that determine whether icons are displayed when bits 5–7 are set to values other than 111b: <ul style="list-style-type: none"> 0: Parking brake status. 1 = active 1–2: Indicates whether the lift or lower function is active: <ul style="list-style-type: none"> 00 = Inactive 01 = Lift active 10 = Lower active 11 = <i>Reserved</i> 3–4: Transmission State: <ul style="list-style-type: none"> 00 = Neutral 01 = Forward gear 10 = Reverse gear 11 = Inactive 5–7: Speed mode: <ul style="list-style-type: none"> 000 = Inactive 001 = High mode 010 = Standard mode 011 = Economy mode 100 = Power mode 101 = Turtle mode 110 = <i>Reserved</i> 111 = Gauge configuration mode. When 111b is specified, bytes 6–7 are used to configure the 3150R as described in Table 7-1.
7	The BDI percentage (when byte 6, bits 5–7 are set to values other than 111b). The displayed data ranges from 0–100%. The raw data ranges from 0–100.

Table 7-1 describes the data for bytes 6–7 when byte 6, bits 5–7 are set to 111b.

Table 7-1 Gauge Configuration (RPDO1, Bytes 6–7)

Byte	Description
6	<p>The following bits configure data sources, pin 8, and logo display:</p> <ul style="list-style-type: none"> • 0 = Whether CAN is the hour meter data source. 1 = active. • 1 = Whether CAN is the BDI data source. 1 = active. • 2 = Whether pin 8 is used as the Switch 3 input or the lift lockout output. 0 = lift lockout output. • 3–4 = Whether a logo is displayed when the device is powered on: <ul style="list-style-type: none"> – 00 = No logo – 01 = Curtis logo – Other values = <i>Reserved</i> • 5–7 = 111 (When these bits are set to a value other than 111b, the device is not in gauge configuration mode.)
7	<p>The following bits configure the user interface:</p> <ul style="list-style-type: none"> • 0–2: Select GUI: <ul style="list-style-type: none"> – 000 = GUI-1 – 001 = GUI-2 – 010 = GUI-3 – 011 = GUI-4 – 100 = GUI-5 – 101–111 = <i>Reserved</i> • 3: = Speed unit. 0 = km/h, 1 = mph • 4–7: <i>Reserved</i>

TPDO1

Byte(s)	Description
0	<p>The following bits indicate various statuses. 0 = inactive, 1 = active:</p> <ul style="list-style-type: none"> • 0 = Switch 1 status • 1 = Switch 2 status • 2 = Switch 3 status • 3 = Lift lockout status • 4–7: <i>Reserved</i>
1	The BDI percentage. The displayed data ranges from 0–100%. The raw data ranges from 0–100.
2	<ul style="list-style-type: none"> • 0–1: The handshake status. When the status is Failed, the device displays the “Comm Failed” error message, otherwise the gauge displays normally: <ul style="list-style-type: none"> – 00 = Idle – 01 = Failed – 10 = Passed – 11 = <i>Reserved</i> • 2–7: <i>Reserved</i>
3	<i>Reserved.</i>
7	Keypad hour meter. The displayed data ranges from 0.0–99999.9 hours. The raw data ranges from 0–999999.

RPDO2

Byte(s)	Description
0–1	Speedometer. The displayed data ranges from 0.0–99.9 km/h or 0.0–62.0 mph, depending upon the speed unit . The raw data ranges from 0–999.
2–3	Lithium battery voltage. The displayed data ranges from 0–99.9V. The raw data ranges from 0–9999.
4	The fault code for the pump controller.
5	The fault type for the pump controller.
6	Indicates statuses that determine whether icons and the left traction controller's fault code are displayed: <ul style="list-style-type: none"> • 0 = Seat icon. 0 = active • 1 = Seatbelt icon. 1 = active. • 2 = Safety pedal icon. 1 = active. • 3 = Guardrail icon. 1 = active. • 4 = Battery charging icon. 1 = active. • 5 = Traction left fault code data source. 1 = CAN. • 6–7 = <i>Reserved</i>. Note: If bit 5 is set to 1, bytes 0–1 of RPDO1 are for the right traction fault code and fault type.
7	Lithium battery fault type.

RPDO3

Byte(s)	Description
0	The fault code for the left traction controller.
1	The fault type for the left traction controller.
2	The fault code for the steering controller.
3	The fault type for the steering controller.
4–7	<i>Reserved</i> .

MESSAGE CENTER

The [message center](#) displays application-specific messages and is available in all GUIs other than GUI 3. Messages are transmitted with block SDO transfers of up to 255 bytes. Message substrings can be formatted for font size and color and can be displayed at any set of coordinates within the message center area.

The message center has a separate node ID, which is specified with the [Message Center Node ID](#) parameter.

The following steps describe the process of transmitting a message:


1. Enable the message center.
2. Format the message.
3. Transmit the message.
4. Clear the message.
5. Disable the message center.

The following topics describe these steps.

Enable and Disable the Message Center

The object with an index and sub-index of 0x7021 : 00 enables and disables messages. The object's data size is one byte. To enable the message center, set the object to 1h.

When the message center is enabled, a rectangle highlights the message center area. Any data normally displayed in that area is hidden while the message center is active. The first example below is for GUIs 1, 4 and 5, and the second is for GUI 2:



The message center's height is 140px. The width depends upon the active GUI:

GUI(s)	Width
1, 4 and 5	240px
2	185px

To exit the message center, set 0x7021:00 to 0h.

Format Messages

The following table describes the message center's default font size, color, and X and Y coordinates:

Item	Format
Font size	<ul style="list-style-type: none"> Width = 13px Height = 20px
Color	White
X and Y coordinates	(0, 19)

You can apply one set of formats to an entire message or different formats to message substrings. Formatting instructions are preceded by opening slashes (/). If multiple substrings of a message are formatted, all instructions other than the last are followed by closing slashes.

If a formatting instruction includes invalid syntax, the device ignores the instruction.

Note: To display a slash, use two slashes (//).

The following tables describe the formatting indicators.

Font Indicator	Font Size
F0	<ul style="list-style-type: none"> Width = 13px Height = 20px
F1	<ul style="list-style-type: none"> Width = 16px Height = 28px

Color Indicator	Color
C0	White
C1	Red
C2	Yellow
C3	Green
C4	Blue
C5	Orange
C6	Gray

Coordinate Indicator	Description
Xn	<p><i>n</i> depends upon which GUI is active and must be in the following ranges:</p> <ul style="list-style-type: none"> GUIs 1,4 and 5: 0–239 (px) GUI 2: 0–184 (px)
Yn	<i>n</i> must be in the range of 19–139 (px)

The X and Y coordinates are measured from the message center area's top left corner. If a line contains substrings with different font sizes, the text is aligned on the bottom.

For example, consider the following message:



The following string defines this message:

```
Information:/X20Y60F1C4/Speed:/X120F0C1/12km//h/X20Y120F1/Fault:
/X120C2/2,3/F0/[1]
```

The following table describes how the message is formatted:

Substring	Description
Information:	The default formats are applied because the substring is not preceded by a formatting instruction.
/X20Y60F1C4/Speed:	“Speed:” is formatted as follows: <ul style="list-style-type: none"> • X and Y coordinates: (20,60) • Font size: F1 • Color: Blue (C4)
/X120F0C1/12km//h	“12km/h” is formatted as follows: <ul style="list-style-type: none"> • X coordinate: 120 • Font size: F0 • Color: Red (C1) The Y coordinate is not specified, so the previously-specified Y coordinate (60) is applied.
/X20Y120F1/Fault:	“Fault:” is formatted as follows: <ul style="list-style-type: none"> • X and Y coordinates: (20,120) • Font size: F1 The color is not specified, so the previously-specified color (red) is applied.
/X120C2/2,3	“2,3” is formatted as follows: <ul style="list-style-type: none"> • X coordinate: 120 • Color: Yellow (C2) The font size and Y coordinate are not specified, so the previously-specified font and Y coordinate are applied.
F0/[1]	“[1]” is formatted with the F0 font size indicator. The other formats are not specified, so the previously-specified color and coordinates are used.

Transmit Messages

Block SDOs are used to transmit messages. A message is displayed after the transfer is ended. The following example describes how to transmit the message for the example in the Format Messages section. The example uses 50h as the message center node ID:

Node ID	Data Bytes (hexadecimal)								Description
	0	1	2	3	4	5	6	7	
0x650	2F	21	70	00	01	00	00	00	Client enables the message center.
0x650	C2	20	70	00	52	00	00	00	Client initiates block download.
0x5D0	A0	20	70	00	7F	00	00	00	Server acknowledges download request.
0x650	01	49	6E	66	6F	72	6D	61	Client transfers segment 1.
0x650	02	74	69	6F	6E	3A	2F	58	Client transfers segment 2.
0x650	03	32	30	59	36	30	46	31	Client transfers segment 3.
0x650	04	43	34	2F	53	70	65	65	Client transfers segment 4.
0x650	05	64	3A	2F	58	31	32	30	Client transfers segment 5.
0x650	06	46	30	43	31	2F	31	32	Client transfers segment 6.
0x650	07	6B	6D	2F	2F	68	2F	58	Client transfers segment 7.
0x650	08	32	30	59	31	32	30	46	Client transfers segment 8.
0x650	09	31	2F	46	61	75	6C	74	Client transfers segment 9.
0x650	0A	3A	2F	58	31	32	30	43	Client transfers segment 10.
0x650	0B	32	2F	32	2C	33	2F	46	Client transfers segment 11.
0x650	8C	30	2F	5B	31	5D	00	00	Client transfers the final segment.
0x5D0	A2	0C	7F	00	00	00	00	00	Server acknowledges the final segment.
0x650	C9	00	00	00	00	00	00	00	Client requests to disconnect.
0x5D0	A1	00	00	00	00	00	00	00	Server confirms the disconnection and the device displays the message.

Clear Messages

Clearing a message removes the message and restores the message center's default formatting. To clear a message, set the 8 bit object with an index and sub-index of 0x7023 : 00 to 1h.

STANDARD CANopen OBJECTS

The following table describes objects required by the CANopen standard:

Name	Index	Sub-Index	Description	Read / Write	Values Data Size
Device Type	1000h	00h	Indicates whether a device follows a standard CiA device profile. The 3150R does not follow a standard CiA profile, so the value is 0.	RO	0 32-bit
Error Register	1001h	00h	Indicates if a fault is active: 0 = No active fault 1 = One or more active faults	RO	0–1 16-bit
Manufacturer Status Register	1002h	00h	<i>Reserved.</i>	N/A	N/A
Manufacturer Device Name	1008h	00h	Initiates a segmented SDO that uploads the model name and number as an ASCII string.	RO	String
Manufacturer's Hardware Version	1009h	00h	Indicates the hardware version.	RO	String
Manufacturer Software Version	100Ah	00h	<i>Reserved.</i> Note: The CDEV and OS Version parameters indicate the software version. See Information Menu Parameters .	N/A	N/A
Emergency COB ID	1014h	00h	Indicates the Emergency Message COB-ID: <ul style="list-style-type: none">• 0: The COB-ID consists of the emergency message function code (0001b) and the node ID.• Non-zero: The COB-ID consists of the emergency message function code (0001b) and the specified value. The COB-ID's four most significant bits represent the emergency message function code.	RO	0–16777215 32-bit
Emergency Message Inhibit Time	1015h	00h	Sets the minimum time that must elapse before another emergency message can be sent.	RW	4–100 (which represents 16–400ms) 32-bit
Heartbeat Rate	1017h	00h	Specifies the cyclic rate of the device's heartbeat messages.	RW	20–2000 (which represents 20–2000ms) 16-bit
Identity Object	1018h	Provides information on the device.			
		00h	Indicates the size of the object.	RO	0–127 8-bit
		01h	Indicates the CiA-assigned identifier of Curtis Instruments. The identifier is 4349h.	RO	4349h 32-bit
		02h	Indicates the device's product code.	RO	0–2147483647 32-bit
		03h	Indicates the device's Curtis CAN protocol version. The upper 2 bytes contain the major version and the lower 2 bytes contain the minor version.	RO	0–2147483647 32-bit
		04h	Indicates the device's serial number.	RO	0–999999 32-bit

APPENDIX A – CURTIS PROGRAMMING DEVICES

Curtis programming devices provide programming, diagnostic, and test capabilities for Curtis CAN devices. Two programming devices are available for the controller:

- 1313 Handheld Programmer
- Curtis Integrated Toolkit™ (CIT)

CIT has the advantage of a large, easy-to-read screen. On the other hand, the 1313 Handheld Programmer is more portable, which makes it convenient for working in the field.

The programming devices include the following features:

- Parameter adjustment. Save and restore the values of programmable parameters.
- Monitoring: Display real-time values during vehicle operation. These values include data for inputs and outputs.
- Diagnostics and troubleshooting:
 - Display active faults and the fault history
 - Clear the fault history
- Flashing: Update firmware of Curtis devices.

The programmers are available for the following access levels. The bullets are sorted from the highest to lowest access level:

- OEM Factory
- OEM Dealer
- Field Advanced
- Field Intermediate
- Field Basic

A Curtis programmer can perform the actions available at or below its access level. For example, a Field Basic programmer can only perform actions available for the Field Basic access level, while an OEM Factory programmer can perform all actions available for any of these access levels.


The following example shows a menu in the CIT Programmer application. You can view or edit a parameter by selecting it on the left-hand side. You can also view and edit all of a menu's parameters in one window by selecting the menu as shown below:

	Name	Device Value	Project Value	Min Value	Max Value
Current	Boost Time	⊖ ⊕ 10 sec	⊖ 10 sec	⊖ 1 sec	⊖ 10 sec
	Regen Current Limit	⊖ ⊕ 60 A	⊖ 60 A	⊖ 10 A	⊖ 60 A
	Interlock Brake Current Limi...	⊖ ⊕ 60 A	⊖ 60 A	⊖ 10 A	⊖ 60 A
	Drive Current Limit	⊖ ⊕ 60 A	⊖ 60 A	⊖ 10 A	⊖ 60 A
	Boost Current Limit	⊖ ⊕ 70 A	⊖ 70 A	⊖ 10 A	⊖ 70 A
	Boost Enable	⊖ ⊕ Off	⊖ Off	⊖ Off	⊖ On

The following example shows the same menu in the Curtis 1313 Handheld Programmer:



To edit a parameter with the 1313 Handheld Programmer, select the parameter:



For more information on the 1313 Handheld Programmer and CIT, see <https://www.curtastinstruments.com/products/programming/>.

APPENDIX B – SPECIFICATIONS

Nominal Voltage	12–48V
Minimum Voltage	9V
Maximum Voltage	60V
Operating Current	<ul style="list-style-type: none"> • LCD heater off: 16–100mA • LCD heater on: 80–350mA
Dimensions	Ø60.0 mm
Operating Temperature	<ul style="list-style-type: none"> • LCD heater enabled: -40°C to +70°C • LCD heater disabled: -20°C to +70°C
Storage Temperature	-40°C to +85°C
Humidity	Designed to the following requirements: <ul style="list-style-type: none"> • Soak: EN 60068-2-78 • Cyclic: EN 60068-2-30
Ingress Protection	Designed to the requirements of EN 60529: <ul style="list-style-type: none"> • Face is sealed to IP67. • Rear is sealed to IP65 for electronic components and to IP40 for the connector. Optional parts can increase the connector's protection to IP54.
Shock	Designed to the requirements of EN 60068-2-27.
Vibration	Designed to the following requirements: <ul style="list-style-type: none"> • General: EN 60068-2-6 • Random: EN 60068-2-64 • Resonance: EN 60068-2-6
EMC	Designed to the following requirements: <ul style="list-style-type: none"> • Radiated Emissions: EN 12895:2015+A1:2019 • Radiated Immunity: EN 12895:2015+A1:2019 • Frequency Magnetic Field Immunity: EN 12895:2015+A1:2019
CE	Designed to the following requirements: <ul style="list-style-type: none"> • EMC: EN 12895:2015+A1:2019 • RoHS: RoHS directive 2015/863/EU (RoHS 3)
UL	UL recognized component per UL583.
Model Encodement	The model number encodement is 3150R1248yrzxx/ where: <ul style="list-style-type: none"> • R = 52mm. • 1248 = 12–48V • y indicates whether the model has a serial port or switch inputs: <ul style="list-style-type: none"> – S = Serial port – D = Switch inputs • r indicates whether the model includes a 120Ω CAN terminating resistor: <ul style="list-style-type: none"> – N = No terminating resistor – T = 120Ω terminating resistor • z is reserved. • xx is a sequential number code. • / indicates the logo on the overlay: <ul style="list-style-type: none"> – O = Curtis logo – C = Customer logo – N = No logo

Note: Regulatory compliance of the complete system with the 3150R installed is the responsibility of the OEM.